

Instruction Manual

DE46 || Digital Differential Pressure Switch / Transmitter

Table of Contents

1. Safety Instructions
2. Intended Applications
3. Product Description and Functions
4. Installation
5. Commissioning
6. Maintenance
7. Transport
8. Service
9. Accessories
10. Disposal
11. Specifications
12. Dimensions
13. Ordering Code
14. Declaration of Conformity



1. Safety Instructions

1.1. General



This manual contains detailed information about the product, and instructions for its installation, operation and maintenance. Operators and other technical personnel responsible for the equipment must read this thoroughly before attempting to install or operate this equipment. A copy of this manual must always be kept accessible at the place of work for reference by concerned personnel.

Chapter 1 (sections 1.2 through 1.7) contains general as well as specific safety instructions. Chapters 2 through 10, covering topics ranging from intended purpose of the equipment to its final disposal, also include important points relating to safety. Overlooking or ignoring any of these safety points can endanger humans and animals, and possibly cause damage to other equipment.

1.2. Personnel Qualification

Personnel responsible for installation, operation, maintenance and inspection of this product must have the qualifications, training and experience

necessary to carry out such work on this type of equipment.

1.3. Risks of Disregarding Safety Instructions

Disregarding safety instructions, use of this product for purposes for which it is not intended, and/or operation of this product outside the limits specified for any of its technical parameters, can result in harm to persons, the environment, or the plant on which it is installed. Fischer Mess- und Regeltechnik GmbH will not be responsible for consequences in such circumstances.

1.4. Safety Instructions for Operators

Safety instructions for the proper use of this product must be followed. This information must be available at all times to by personnel responsible for installation, operation, maintenance and inspection of this product. Adequate steps must be taken to prevent the occurrence of hazardous conditions that can be caused by electric energy and the convertible energy of the process media. Such conditions can, for example, be the result of improper electrical or process connections. Detailed information is available in relevant pu-

blished norms (DIN EN, UVW in Germany; and equivalents in other countries), industrial standards such as DVWG, Ex-, GL-, VDE guidelines, as well as regulations of the local authorities (e.g., EVUs in Germany).

1.5. Modifications Forbidden

Modification or other technical alteration of the product is not permissible. This also applies to the use of unauthorized spare parts for repair / maintenance of the product. Any modifications to this product, if and as necessary, should be done only by Fischer Mess- und Regeltechnik GmbH.

1.6. Operational Restrictions

The operational reliability of the product is guaranteed only when used for intended purposes. The product must be selected and configured for use specifically with defined process media. The limiting values of operating parameters, as given in the product specification sheet, must never be crossed.

1.7. Safety Considerations during Installation and Maintenance

The safety instructions given in this manual, existing national regulations relating to accident prevention, and the internal safety rules and procedures of the user organization regarding safety during installation, operation and servicing must all be followed meticulously.


It is the responsibility of the users to ensure that only suitably qualified and experienced technical personnel are used for installation, operation and servicing of this equipment.

2. Intended Applications

The product includes the functions of sensing, signal conversion, display, signal transmission, and limit detection of pressure / differential pressure of gases. The product must be used only for applications and under conditions specified by the manufacturer. In case of uncertainties, the user should consult the manufacturer before installing and using the product.

3. Product Description and Functions

3.1. Functional Scheme



3.2. Principles of Operation

The instrument is based on a capacitance sensor element and can measure positive gauge, negative gauge or differential pressure.

The pressure is measured directly by a micromachined silicon-on-glass capacitance sensor element. The instrument's internal microcontroller transfers the measured value to its LED display and operates the two internal limit relays whose contacts are used for alarm and/or control functions. With the transmitter option, the measured value is transmitted as a voltage or current signal output after conversion by a D/A converter stage.

4. Installation

The electronic module is mounted on a flat plate or panel, for which it has 4 holes at the rear for self-tapping screws Ø3.5 mm.

A wall-mounting rear adaptor plate is available as an option (s. 13. Ordering Code).

The pressure transmitters are calibrated at the factory while mounted vertically, pressure ports downward. However, they can be mounted in any orientation. If they are installed with any orientation other than vertical (pressure ports downward), the zero point must be re-set (s. 5.3.2.).

IP65 protection for the housing is guaranteed only if suitable connecting cable is used.

If the instrument is intended for outdoor application, we highly recommend using an adequate protective housing (or at least a big enough shelter) as protection against UV-radiation on the membrane keyboard and against exposure of the instrument to rain or snow.

4.1. Process Connections

- Only technicians who are qualified and authorized for this type of work should undertake installation.
- Ensure that the process equipment and pressure lines are at atmospheric pressure before making pressure connections to the instrument.
- The instrument should be provided with suitable protection against pressure surges (e.g., snubber or pulsation damper).
- Ensure that the mechanical configuration and materials of construction of the instrument are compatible with the process media.
- Ensure that process pressure is always less than the specified safe pressure rating.
-  **Do not blow into the pressure connections!**

4.2. Electrical Connections

- Only technicians who are qualified and authorized for this type of work should undertake installation.
- Electrical connections must be conform to relevant international, national and local regulations and norms relating to electrical and instrumentation installations.
- Switch off electrical power to the plant before attempting electrical installation work of any kind.
- Make electrical connections to the instrument through a suitable fuse.
- Carefully check the pressure-tightness of all pressure connections before start-up.

5. Commissioning

- All lines to the instrument must be correctly selected to meet operational requirements, and installed in way that does not cause physical stress to the instrument.
- If pressure lines are used to connect the pressure instrument and the process vessel / pipe, the pressure lines must have a downward gradient throughout, from the pressure instrument to the process vessel / pipe. This is to prevent formation of liquid plugs (for air / gas applications). If this continuous downward gradient cannot be provided for any reason, then suitable water separation devices must be inserted in the pressure lines.

- Pressure lines must be kept as short as possible and must not have short bends to avoid measurement errors induced by pressure line delays.

5.1. Pressure Connections

The instruments pressure ports are marked by "+" and "-" symbols. For differential pressure applications the "+" port must be connected to the higher pressure and the "-" port should be connected to the lower pressure.

If the pressure transmitter is subjected to pressure when it is started up, zero point checking and adjustment is not possible. In such cases, only electrical connections of the instrument should be made, but not the pressure connections.

5.2. Display



The 3½ digit LED display normally indicates the current differential pressure. The back-lighted symbols to the right of the 3½ digit LED display indicate the unit of pressure measurement. (Note: the units shown in the illustrations of this document can be different from those of the actual instrument). The two LED lamps above the 3½ digit LED display respectively indicate the status of the two limit relays / solid-state switches ① ② (LED on = relay contacts closed / solid-state switch on).

While the instrument is in set-up mode, the 3½ digit LED display either indicates the selected menu option or a set-up parameter value. The instrument continues its pressure monitoring functions even while it is in set-up mode, except under either of two circumstances.

One is when the limit switching delay time is changed: the existing delay must time out first. The other is when the look-up table (for conversion of measured values) is re-programmed (s. 5.3.7.). In these circumstances, the output signal value and the limit relay/switch states are frozen until the changes are finalized.

5.3. Set-up

The instrument has comprehensive set-up options by means of which it can be optimized for any specific measuring or control application. This section of the document provides information and instructions about each of the set-up parameters.



Depending on the instrument configuration ordered (e.g.: without transmitter signal output / with voltage signal output / with current signal output) some of the menu options may not available. Some set-up parameters may be consequentially excluded. For example, if the instrument is ordered without a transmitter output, all signal conversion programming options are omitted in the set-up menu (s. 5.3.6. Signal Conversion and Transfer Functions).

All instrument settings can be conveniently done from a PC connected to the instrument through a serial interface adaptor. All set-up parameters can be viewed and changed on the PC screen. Also, the entire instrument set-up configuration can be loaded, stored on the PC's hard disk drive, and printed out for plant / process documentation purposes. Further information about this PC software is given in the software documentation.

5.3.1. Selecting the Unit of Pressure Measurement

Make the necessary electrical connections (signal, power supply) to the instrument. Its pressure sensor/s must be pressure-free (i.e., vented to atmosphere; typically by disconnecting the pressure line/s).

The current valid unit of measurement is indicated by one of the back-lighted symbols to the right of the digital display. To change the unit of measurement, first press \blacktriangleright then search for parameter ***Ein*** using \blacktriangleleft . Next press \blacktriangleright again and select another unit of measurement using \blacktriangleleft or \blacktriangleright . Then press again \blacktriangleright to store the selection, and ***Ein*** will appear again in the digital display.

To exit the set-up mode, press \blacktriangledown until ***ESC*** appears, and then press \blacktriangleright . The current pressure measured value is indicated again, and the appropriate symbol of the unit of measurement (to the right of the digital display) is lighted.



The digital display is limited to a count of ± 1999 . Therefore, not all available units of measurement may be suitable for selection for a given application.

5.3.2. Zero Point Checking and Adjustment

If the instrument has been de-pressurized (vented to atmosphere) and does not indicate precisely zero, note this non-zero value. Using the set-up parameter ***oFl***, you can

trim this offset to exactly zero. If the indicated non-zero value is positive, this value must be entered and stored as a negative offset value, and vice versa.



If the instrument was in use before zero setting is done, values of set-up parameters ***oFl*** and ***nP*** would have been previously programmed. In this case, set both values to zero, read the actual zero offset, and then use this value for ***oFl*** for zero point correction, as described in the previous paragraph.

Note: The registered value is a pure number: no decimal point is indicated.

After correcting the zero offset, the pressure connections can be made again.

5.3.3. Damping and Zero Stabilization

If the media is subject to excessive pressure fluctuations, the displayed readings and the transmitter output signal can be stabilized using the instrument's ***dRn*** and ***nP*** set-up parameters.

The set-up parameter ***dRn*** has the effect of a pulsation damper (on the displayed measurements, output signal and limit detection, - not on the sensor itself!). It adds a time-constant (averaging filter) in the user selectable range of 0.0 to 100.0 secs. When the damping is set to maximum, it takes more than 2 minutes to reach the final value for a full scale pressure jump.

In many cases fluctuating pressure readings do not cause a problem, except when the plant / equipment is at zero (differential) pressure condition and readings fluctuate near about zero value. The set-up parameter ***nP*** is meant to take care of this. Its value defines the number range across zero (similar to the zero offset correction number), within which the measured value is forced to zero. If a value of 8 is set for ***nP*** any pressure measurement in the range -0.08 to +0.08 mbar (or -8 to +8 Pa) displayed as zero. Only when the actual pressure is outside this range will the display indicate a non-zero value. The actual and displayed pressures will agree starting from double the value of the ***nP*** setting (in the given example: 0.16 mbar or 16 Pa).

5.3.4. Output Signal Setting

The transmitter output signal depends primarily on the measured pressure. However, this signal can be adjusted to meet users' application requirements precisely. The basic pressure range (as marked on the product identification label) and the type of output signal (voltage or current) always remain unchanged for a particular instrument unit.

The set-up parameters ***NR*** (measuring range starting point) and ***NE*** (measuring range end point) specify the pressure values between which the measurements are expected to be. Both values can be selected anywhere within the specified measuring range of the instrument (e.g., 400 Pa). This user-programmed pressure range will correspond to the output signal (current or voltage) range, which will be as specified on the product identification plate: i.e., 0 - 10V or 4 - 20 mA.

If ***NR*** is lower than ***NE***, the signal is said to have a positive slope: i.e., the output signal increases as the pressure increases. If ***NE*** is lower than ***NR***, the output signal has a negative slope: i.e., the output signal decreases as the pressure increases.

The difference between the values of ***NR*** and ***NE*** must be at least 25% of the specified measuring range of the instrument (100 Pa for 400 Pa instrument example mentioned above). The software does not permit a smaller pressure span to be entered (the instrument will not allow storing of, nor exit from an invalid span).

Note: If you change ***NR*** and/or ***NE*** the look-up table (s .5.3.6., 5.3.7.) that existed up to that instant is deleted!



5.3.5. Output Signal Limiting (Namur)

The three set-up parameters ***oGl***, ***oG2*** and ***oEr*** specify the limits of the signal output current or voltage that are not to be exceeded, irrespective of the actual pressure. These limit values have higher priority than the ***NR*** and ***NE*** pressure span settings.

These settings serve mainly to prevent control systems from interpreting brief pressure excursions outside the measuring range as error / fault events. ***oGl*** sets the output signal minimum value, and is useful only for a 4 - 20 mA current signal, because sometimes a value below 3.8 mA is defined as a sensor fault condition. ***oG2*** sets the upper signal limit and is valid for either current or voltage signal (e.g., voltage signal output can be limited at 10.2 V).

An instrument fault condition can be transmitted as an output signal value set as parameter ***oEr***. However, it should be understood that not all instrument fault and error conditions can be detected and signaled by the self-diagnostic functions of the instrument.

5.3.6. Signal Conversion and Transfer Functions

In certain cases other process variables are derived from primary pressure measurement. Examples are flow rate derived from differential pressure across an orifice plate, and liquid level derived from hydrostatic pressure of liquid measured at the bottom of the tank. Such derivations often involve non-linear transfer functions, while it is necessary for the output signal to be linearly proportional to the derived variable (e.g. liquid volume in a tank in m³, or flow rate in cm³/sec).

The set-up parameter ***F*** allows the user to select the appropriate signal conversion function from those available:

- ***F=0***: linear characteristic (default)
- ***F=1***: square root extraction
- ***F=2***: horizontal cylindrical tank
- ***F=3..30***: look-up table with 3 to 30 pairs of values

The tables generated by functions ***F = 0***, ***F = 1*** and ***F = 2*** are not visible. For these functions, internal values are used for table computation. These values cannot be modified directly in the table by the user.

For all conversion functions, when the actual pressure is equal to the ***NR*** value, the output signal will be at the lowest end of its range (0 V, 0 mA or 4 mA). When the actual pressure is equal to the ***NE*** value, the output signal will be at the highest end of its range (10 V or 20 mA). The user can enter only the 1...28 intermediate values of the look-up table function ***F = 3....30***. The parameters ***NR*** and ***NE*** relate to the start and end values of the look-up table. A change in either of these parameter values causes the conversion function to be re-set to ***F = 0***.



Whenever the value of ***F*** is changed, the instrument internally generates a new look-up table. All previous table values are deleted and replaced by new linear progression values.

5.3.7. Look-up Table Programming (***F = 3..30***)

If the value of set-up parameter ***F*** is selected equal to or greater than 3, a sub-menu ***Lin*** is invoked. Through this sub-menu all the required look-up table values can be entered, except the first and last pairs of table values (respectively corresponding to ***NR*** and ***NE***). This sub-menu has its own entry and exit points, the latter being the last of the value pairs to be entered. The table is stored only when the user exits to the sub-menu prompt ***Lin***, by pressing ***◆***. If the table is not correctly entered, the display will indicate ***Err***, indicating an error condition. If this happens, it is not possible to exit this sub-menu mode until the error is corrected.

The table entries consist of 1 to 28 pairs of values. Values ***102*** through ***129*** (or ***u02*** through ***u29***) specify the amplitude of the out the signal output, and the values ***P02*** through ***P29*** are the corresponding pressure values.

Entering or changing table values through the instrument's membrane keyboard is a tedious and error-prone method. It should only be used as a stopgap method when a PC and/or the PC Interface Module is not available.

The table is accepted as correct if each output value is larger than its preceding value. Pressure values can be steadily increasing or steadily decreasing. However, a transition from falling to rising pressure values is not permitted; nor are pressure values allowed to turn back along the same curve.

5.3.8. Limit Setting

The two limit switching outputs **①** **②** (relay contacts or solid-state switches) are each configured by four set-up parameters:

Switching output 1 is configured by parameters ***r1R***, ***r1E***, ***r1d*** and ***r1F***.

Switching output 2 is configured by parameters ***r2R***, ***r2E***, ***r2d*** and ***r2F***.

The turn-on and turn-off points of switching output 1 are defined respectively by parameters ***r1R*** and ***r1E***. The values for these are set in the currently valid unit of measurement (indicated by the lighted symbol to the right of the digital display).

The two parameters ***r1R*** and ***r1E*** together determine the logic of switching output 1:

If ***r1R*** is smaller than ***r1E***, the output turns on when the measured value exceeds ***r1E***. It turns off again only when the measured value falls below ***r1R*** (hysteresis function).

If ***r1R*** and ***r1E*** have the same value, there is no hysteresis: the switching output turns on when the measured value exceeds ***r1R*** / ***r1E***, and turns off again when the measured value falls below ***r1R*** / ***r1E***.

If ***r1R*** is larger than ***r1E***, the switching output turns on when the measured value falls between ***r1R*** and ***r1E***: i.e., when ***r1E*** < measured value < ***r1R*** (window limit function).

Both parameters can be independently adjusted over the full measuring range.

If the unit of measurement is changed, the switching points are changed accordingly. In this event, rounding

error can cause a deviation in the least significant (right-most) digit.

The value of the set-up parameter ***r1d*** determines the delay time for switching output 1, after the measured value reaches the switching point. The delay value can be selected in the range 0.0 to 100.0 secs. This value applies equally to turn on and turn off.

The set-up parameter ***r1F*** determines the action of the switching output. If ***r1F*** = 1, the switching output acts as normally open (NO) contacts. If ***r1F*** = 2, it acts as normally closed (NC) contacts.

5.3.9. Password

The last set-up parameter allows a password to be entered. A password value of 001 to 999 can be selected. A value of "000" disables the password function.

If a password was set previously the digital display indicates ***PAS*** after ***ESC*** is displayed and ***◆*** is pressed. The password is then entered, by pressing ***◆*** and then ***▲*** and ***▼***. Only then will the set-up menu options be accessible. If an incorrect password is entered, the display jumps back to beginning of the menu (i.e., ***ESC***).

New Functions! (as of April 2008)

5.3.10. ***d0*** – Display options

This parameter allows smoothing the displayed values in cases where they are frequently deviating. The filter function is similar to the ***dRn*** function, but acts only upon the display, having no impact on the output signal. Additionally the display can be turned off partially (***d0*** = -1, only the setpoint LEDs are driven) or completely (***d0*** = -2).

5.3.11. ***rES*** – Reset to default values

This function will reset all parameters to default when activated. Default values can be defined only by using the PC interface.

5.3.12. ***NRF***, ***NEF***, ***dPF*** – Free Unit

If the device is configured to have a "free" third unit (symbol: ***▼***) then the display can be scaled as desired by using these three parameters.

The measuring range as defined by parameters ***NR*** and ***NE*** is rescaled to ***NRF*** and ***NEF***. If the table function (F) is enabled, table values will be taken into account too. The ***dPF*** value controls the position of the decimal point.

5.4. Overview of Set-up Parameters

When the instrument is turned on, it briefly displays the software version number, and then switches automatically to normal operating mode. Pressing \Rightarrow causes the set-up menu to be called up, indicated by **ESC** on the digital display. After that, by pressing \blacktriangle repeatedly, each of the set-up parameters is called up in sequence:



Note: Depending on the version of the instrument that was ordered some of the individual parameters might not be available.

- **P_{AS}** Password input (appears only if password function has been enabled). Values: 001 to 999
- **d_R** Damping (time constant). Range of values = 0.0 to 100.0 secs
- **d_O** Damping (display only), range of values 0..100. Additional: -1 = no digital value and -2 = display turned off completely.
- **r_{1R}** Switching output 1: turn-off point.
- **r_{1E}** Switching output 1: turn-on point.
- **r_{1d}** Switching output 1: delay. Range of values = 0.0 to 100.0 sec. This values applies equally for turn-on and turn-off delays.
- **r_{1F}** Switching output 1 action. If **r_{1F}** = 1, acts as NO contacts. If **r_{1F}** = 2, acts as NC contacts.
- **r_{2R}** Switching output 2: turn-off point.
- **r_{2E}** Switching output 2: turn-on point.
- **r_{2d}** Switching output 2: delay. Range of values = 0.0 to 100.0 sec. This values applies equally for turn-on and turn-off delays.
- **r_{2F}** Switching output 2 action. If **r_{2F}** = 1, acts as NO contacts. If **r_{2F}** = 2, acts as NC contacts.
- **E_{in}** Unit of measurement. The selection is indicated by the lighted symbol to the right of the digital display. A particular unit can be selected only if it can be meaningfully represented within the basic measuring range of the instrument.
- **l_R** Measuring range start point. The value of the measured variable corresponding with the minimum value of the output signal (0 V, 0 mA or 4 mA, depending on the instrument version).
- **l_E** Measuring range end point. The value of the measured variable corresponding with the maximum value of the output signal (10 V or 20 mA, depending on the instrument version).
- **d_{PF}** Position of decimal place for free unit.
- **l_{RF}** Measuring range start point (displayed value) for free unit.

- **l_{EF}** Measuring range end point (displayed value) for free unit.
- **o_P** Zero stabilization. Range = 0 to 100 counts. The value spans symmetrically around the actual zero point.
- **o_{FI}** Zero offset correction, input 1. Range = -100 to +100 counts.
- **F** Signal conversion function. (0 = linear, 1 = square root, 2 = horizontal cylindrical tank, 3..30 = look-up table)
- **Lin** Look-up table entry (sub-menu)
- **o_{U1}** Output signal limiting, minimum
- **o_{U2}** Output signal limiting, maximum
- **o_{Er}** Fault signaling (output signal value on detection of instrument fault).
- **r_{ES}** Reset all values to default. (Default values can be defined only by using the PC interface.)
- **-P-** Password setting. Permissible password values = 001 to 999. "000" disables password protection.



If the password is lost, the instrument can be unlokked only through a serial interfaced PC, or the instrument has to be sent to the manufacturer for this purpose.




If **o_{U1}** and **o_{U2}** are both set to "0", the output signal will not be subjected to limiting.



If **o_{U1}** is set at the maximum value (11 V or 21 mA), the output signal can be adjusted using **o_{U2}** to any arbitrary value between zero and maximum value, irrespective of pressure measurement. This feature enables the instrument to be used as a simulated signal source to test signal lines and other instruments or systems.

5.5. Electrical Connections, Switching Outputs



Switching Outputs:

Switching output 1 is configured by parameters rIR , rIE , rId , and rIF .

Switching output 2 is configured by parameters rIR , rIE , rId , and rIF .

Power Supply Voltage and Output Signal Load:

Nominal supply voltage and the operating supply voltage range are indicated under 11. Specifications.

The maximum output signal loads are indicated under 11. Specifications.

The signal ground line is internally connected to the instrument ground, and serves only as an alternative ground connection for the output signal. This usually increases the noise margin.

6. Maintenance

The instrument is inherently maintenance-free.

However, to ensure reliable operation and maximize the operating life of the instrument, it is recommended that the instrument, its external electrical and process connections, and external connected devices be regularly inspected, e.g.:

- Check the display.
- Check the switching output connections and external devices that are connected to these
- Check all pressure connections for leak-tightness
- Check the integrity of all electrical connections of the instruments

Inspection and test schedules depend on operating and site conditions. The operating manuals of other equipment to which the instrument is connected must be read thoroughly to ensure that all of them work correctly when connected together.

7. Transport

The product must be protected against shock and vibration during transport. It must therefore be properly packed, preferably in the original factory packaging, whenever it is to be transported.

8. Service

Any defective devices or devices with missing parts should be returned to Fischer Mess- und Regeltechnik GmbH. For quick service contact our service department.



Remaining medium in and on dismantled measuring instruments may cause danger to persons, environment and equipment. Take reasonable precautions! Clean the instrument thoroughly if necessary.

9. Accessories

- Wall mounting adaptor plate (s. Ordering Code).
- Panel mounting kit (s. Ordering Code).
- M12 connectors with pre-wired cable lengths: on request.
- PC serial interface adaptor with software: model EU03.F300.

10. Disposal

Protect your environment!



Use the product in accordance with relevant regulations. Please be aware of environmental consequences of disposal at the end of the product's life, and take care accordingly.

11. Specifications

General

Base measuring range	Pa	0-25	0-50	0-100	0-250	0-500	0-1000	-12.5...+12.5	-25...+25	-50...+50	-100...+100
Max. static operating pressure	bar							1.0			
Max. safe pressure	bar							1.7			
Straight line error (max.)°	%FS							1.0			
Repeatability°	%FS							0.1			
TC span and offset max.°°	%FS 10K							0.6			

° Straight-line error = nonlinearity + hysteresis; at 25 °C; default output scaling (f.s. = pressure range end value); linear output.

°° Pressure within specified range; compensated temperature range 4 to 50 °C

Operating temp. (ambient)	-10 ... 70°C
Operating temp. (media)	-10 ... 70°C
Storage temperature	-20 ... 70°C
Protection class housing	IP 65 per DIN EN 60529
Electrical	
Nominal supply voltage	24 V DC / AC
Operating supply voltage	20 ... 32 V DC / AC
Output signal	0 ... 20 mA, 4 ... 20 mA, 0 ... 10 V DC (3-wire)
Output signal load impedance	for current output $R_L \leq (U_B - 4 V) / 0.02 A$ ($U_B \leq 26V$), else $R_L \leq 1100 \Omega$ for voltage output $R_L \geq 2 K\Omega$ ($U_B \geq 15 V$), $R_L \geq 10 K\Omega$ ($U_B = 12 \dots 15V$)
Power consumption	approx. 2 W / VA
Limit relay contact	2 relays, potential-free contacts, NO or NC (user setting) $U_{max} = 32 V$ DC/AC; $I_{max} = 2 A$; $P_{max} = 64 W/VA$ Alternatively: 2 solid-state switch (MOSFET) outputs, SPST, N/O or N/C (user setting) $U = 3$ to $32 V$ DC/AC; $I_{max} = 0.25 A$; $P_{max} = 8 W/VA$; $R_{ON} \leq 4 \Omega$
Display	3½ digit LED display
Connections, Materials, Mounting	
Electrical connections	2 x M12 round-shell multi-pin connectors Connector 1: Signal output & supply input (5-pin male socket) Connector 2: Contact outputs (4-pin male socket)
Pressure connections	Screw clamp connectors (aluminum) for 6/4 mm or 8/6 mm tube
Materials housing	Polyamide PA 6,6
Materials, media contact	Silicon, PVC, aluminum, brass
Mounting	Rear mounting holes for back-panel mounting Wall mounted with mounting plate

11.1. Programming


The DE46 can be programmed either through its membrane keyboard and menu-assisted prompting, or from a PC using the EU03 PC adaptor (optional accessory). Password locking is possible..

	Settings:
Damping	0.0 to 100.0 sec (10 / 90 % step response time) for signal output, display separated
Relays 1 & 2 functions	Normally energized or normally de-energized; switching delay (0 to 100 sec.); N/C or N/O
Unit of measurement	mbar / Pa / „free unit“ start value, end value and decimal place for „free unit“
Zero stabilization	0 to 100 counts of least significant digit (1)
Measuring range min. / max.	Basic measuring range min. / max. (2)
Zero adjustment	± 100 counts of least significant digit (3)
Output signal transformation	Linear, square root, horizontal tank volume, look-up table (3 to 30 points)
Password	001 to 999 (000 = password lock disabled)


Notes:

- (1) Measured values within ± 100 counts of zero are displayed as exactly zero (i.e., zero drift is suppressed).
- (2) Turndown ratio = 4:1 max. Only the output signal is affected. Downward sloping output signals are also possible when the starting value of the measuring range is greater than the ending value.
- (3) Zero adjustment may be needed for mounting orientation other than vertical.


12. Dimensions (all units in mm unless stated otherwise)



Optional panel mounting kit



Electrical connections



13. Ordering Code

Digital Differential Pressure Switch / Transmitter	DE46	[]	[]	#	#	[]	[]	[]	N	#	[]	M	[]
Measuring Range													
0 ... 25 Pa	> D	1											
0 ... 50 Pa	> J	6											
0 ... 100 Pa	> D	4											
0 ... 250 Pa	> D	6											
0 ... 500 Pa	> J	7											
0 ... 1000 Pa	> D	9											
- 12.5 ... + 12.5 Pa	> L	4											
- 25.0 ... + 25.0 Pa	> L	5											
- 50.0 ... + 50.0 Pa	> L	2											
- 100.0 ... + 100.0 Pa	> L	7											
Pressure Connection													
Screw clamp connectors (aluminum) for 6 / 4 mm tube	> 4	0											
Screw clamp connectors (aluminum) for 8 / 6 mm tube	> 4	1											
Signal Output													
Without analogue signal output	>	0											
0 - 20 mA linear, 3-wire	>	A											
0 - 10 V DC linear, 3-wire	>	C											
4 - 20 mA linear, 3-wire	>	P											
Power Supply Input													
24 V DC/AC nominal (20-32 V DC/AC operating)	>	N											
Display / Switching Output													
3½ digit LED display with 2 relays (potential-free contacts)	>	3											
3½ digit LED display with 2 solid-state switch outputs	>	6											
Electrical Connection													
M12 round-shell multi-pin connectors (sockets)	>	M											
Mounting													
Standard: rear fastening holes for self-tapping screws	>	0											
Mounting rail	>	S											
Front panel mounting adaptor kit	>	T											
Wall mounting plate	>	W											
Shaded features are not indicated in data sheet and only available on request!													

Accessories

Ordering Code	Description	Pins	Function	Length
06401993	M12 connector plug with cable	4	Switching outputs	2 m
06401994	M12 connector plug with cable	4	Switching outputs	5 m
06401995	M12 connector plug with cable	5	Supply + signal	2 m
06401996	M12 connector plug with cable	5	Supply + signal	5 m
04005144	Wall mounting plate			
EU03.F300	PC programming adaptor with software			

14. Declaration of Conformity



EG-Konformitätserklärung

Wir erklären in alleiniger Verantwortung, dass nachstehend genannte Produkte

EC Declaration of Conformity

We declare under our sole responsibility that the products mentioned below

Drucktransmitter / Pressure Transmitter

DE46 # ##### # # # # # # #

gemäß gültigem Datenblatt übereinstimmen mit der

specified by the actual data sheet complies with the

EG-Richtlinie

EC Directive

2004/108/EG (EMV)

2004/108/EC (EMC)

Die Produkte wurden entsprechend den folgenden Normen geprüft (Störfestigkeit für Industriebereich, Störaussendung für Wohnbereich):

DIN EN 61326-1:2004-05
DIN EN 61326-2-3
DIN EN 61010-1:2002-08

The instruments have been tested in compliance with the norms (Immunity for industrial environments, emission for residential environments)

DIN EN 61326-1:2004-05
DIN EN 61326-2-3
DIN EN 61010-1:2002-08

Die Geräte werden gekennzeichnet mit:

The gauges are marked with:

CE



(rechtsverb. Unterschrift / authorized signature)

Bad Salzuflen, 05.12.07
(Ort, Datum / place, date)

Fischer Mess- und Regeltechnik GmbH Bielefelder Straße 37a 32107 Bad Salzuflen UST-IdNr.: DE124602659 Steuer-Nr.: 313/5729/0559	Fon: (052 22) 97 40 Fax: (052 22) 71 70 Internet: www.fischermesstechnik.de eMail: info@fischermesstechnik.de	Sparkasse Lemgo (BLZ 462 50 10) Kto-Nr.: 1 841 BIC: WELADED1LEM IBAN: DE90482501100000011841	Postbank Hannover (BLZ 250 500 00) Kto-Nr.: 0201 830 307 BIC: PBNKDEFF IBAN: DE98250100300201830307	Sitz: Bad Salzuflen Amtsgericht Lemgo HRB 226 Geschäftsführer: Gunter B. Gödde
---	---	--	---	--

Technische Änderungen vorbehalten • Subject to change without notice • Changements techniques sous réserve

Fischer Mess- und Regeltechnik GmbH • Bielefelder Str. 37a • D-32107 Bad Salzuflen • Tel. +49 5222 9740 • Fax +49 5222 7170
eMail: info@fischermesstechnik.de • www.fischermesstechnik.de