



Data Sheet

DA03 | D

Differential pressure - Measuring device

Pressure levels PN40/PN100

The differential pressure - measuring device DA03 serves the direct display of differential pressures and can be equipped with the following additional equipment:

- Contacts in sliding and magnetic spring switches
- Inductive contacts acc. to NAMUR
- electrical angular position transducer

Important features

- highly corrosion resistant
- · sturdy, wear-free measuring unit
- · resistant to dirt
- rinsable pressure chambers

Application scopes

- · Chemical, petrochemical industry
- Process engineering
- · Marine and offshore technology
- Power plant technology

Design and mode of operation

The pressures that are to be compared are each exerted onto a measuring membrane that can be rigidly connected to each other using a connection rod.

To compensate the static pressure, the space between the measuring membranes is filled with a pressure transfer fluid.

If the pressure equalised, both measuring membranes are in their idle positions. In case of pressure difference, the force acting on the measuring membrane causes it to be moved towards the side of the lower pressure.


The movement of the measuring membranes is transferred via a connecting rod to a transfer lever mounted to the measuring shaft. Proportional to the current differential pressure, the measuring shaft rotates and this is transferred to a rotational angle of between 0 and 270° via the needle mechanism.

In the case of one-sided pressure by the measuring system above and beyond the measuring range,



the over-pressure guard will be activated. The overpressure causes the overloaded membrane and its band to be pressed against the inner O-ring. This creates two separate pressure spaces between the measuring membranes that need to be filled with fluid. In the adjacent pressure space, a corresponding over-pressure is created. The measuring membrane is supported by the contained transfer fluid. In this way the measuring membranes compensate the forces acting upon them.

Functional Schematic





Technical data

| Technical design | Nominal pressure ¹ | Measuring cell | Application information | | | | | | | |
|------------------|-------------------------------|-------------------|---|--|--|--|--|--|--|--|
| DA03 G | PN40 | Ø75 (small) | Measuring ranges: 00.6 mbar to 025 bar Allowed ambient temperature -20 °C +80 °C | | | | | | | |
| | | | Remote seals: It is possible to attach remote seals for measuring ranges ≥ 0.6 mbar. The remote seals need to be designed for the displacement volume, the length of the cable and the application temperature. | | | | | | | |
| DA03 K | PN100 | Ø75 (small) | Measuring ranges: 00.6 mbar to 025 bar Allowed ambient temperature -20 °C +80 °C | | | | | | | |
| | | | Remote seals: It is possible to attach remote seals for measuring ranges ≥ 0.6 bar. The remote seals need to be designed for the displacement volume, the length of the cable and the application temperature. | | | | | | | |
| DA03 H | PN40 | Ø130 (large) | Measuring ranges: 040 mbar to 0400 mbar Allowed ambient temperature -20 °C +80 °C | | | | | | | |
| | | | Limitations: Trailing needle measuring ranges ≥ 60 mbar Contacts / transmitter measuring ranges ≥ 100 mbar | | | | | | | |
| | | | Remote seals: It is possible to attach remote seals for measuring ranges ≥ 160 mbar. The remote seals need to be designed for the displacement volume, the length of the cable and the application temperature. | | | | | | | |
| DA03 L | PN100 | Ø130 (large) | Measuring ranges: 040 mbar to 0400 mbar Allowed ambient temperature -20 °C +80 °C | | | | | | | |
| | | | Limitations: Trailing needle measuring ranges ≥ 60 mbar Contacts / transmitter measuring ranges ≥ 100 mbar | | | | | | | |
| | | | Remote seals: It is possible to attach remote seals for measuring ranges ≥ 160 mbar. The remote seals need to be designed for the displacement volume, the length of the cable and the application temperature. | | | | | | | |
| | | | | | | | | | | |

| General | points |
|---------|--------|
|---------|--------|

Rated pressure of the measuring

system

Measuring accuracy Overload capability Max. static operating pressure

±1.6 % of the measuring range

on-sided over-pressure-proof up to the rated pressure of the measuring system resistance to under-pressure on the (+) and (-) side

Zero-point adjustment

±25 % of the measuring range (can be access through the upper opening in the display housing)

Admissible ambient temperature Admissible media temperature Admissible storage temperature Temperature sensor

-20 °C ... +80 °C max. 100 °C

approx. 0.3% / 10 °C

Measured Value Display Pressure chambers Enclosure protection class Round housing NG100 or NG160

smooth walls without undercuts; flat measuring membranes

IP65 as per DIN EN 60529

Connections

Process connection

Flange connection based on DIN EN 61518 with internal thread G½ various connection ports; cutting ring screw connections (see order code)

Purge and venting connection

Inner thread G1/2 per pressure cap; closed with a sealing plug

¹ Rated pressure of the measuring system



Materials

Design of the measuring system

Pressure caps (contact with the medium) Measuring membranes (contact with the medium) CrNi-steel 1.4404 (AISI 316L)

Measuring ranges ≤ 400 mbar: CrNi-steel 1.4571 (AISI 316Ti) Measuring ranges ≥ 0.6 bar : NiCrCo alloy. DURATHERM®

Design of the measuring system

Pressure caps (contact with the medium) Measuring membranes (contact with the medium) Code H

Hastelloy® C276

Measuring ranges ≤ 2.5 bar Measuring ranges ≥ 4 bar

: Hastelloy® C276

: Standard membrane with separator film Hastelloy® C276 The model with the separator foil is not suitable for

underpressure.

Design of the measuring system

Pressure caps (contact with the medium) Measuring membranes (contact with the medium) Code G

CrNi-steel 1.4404 (AISI 316L)

Measuring ranges ≤ 2.5 bar Measuring ranges > 4 bar : Hastelloy® C276

Measuring ranges ≥ 4 bar : Standard membrane with separator film Hastelloy® C276

The model with the separator foil is not suitable for

underpressure.

Intermediate plate Needle mechanism and housing

Window
Dial face and needle
Gaskets

AIMgSiPb HART-COAT®
CrNi-steel 1.4301 (AISI 304)
Safety laminated glass
aluminium

Viton® O-rings

Additional Attachments

Additional electrical attachments

Limit signal transmitters (mechanical sliding, snap action or inductive contacts) and capacitive angular position transducers with output signal can be built into a housing augmented by a corresponding bayonet ring connector.²

The measuring deviation increases by $\pm 0.5\%$ per contact due to the operation and switching of the contacts.

Fluid charging

If there are built-in contacts with silicone oil, the housing can be filled with glycerine if the meter is to operate under aggravated operating conditions such as vibrations and extreme pressure fluctuations, or in order to avoid condensate formation if used out of doors.

Marker needle

Adjustable needle in the window for noting the limit values

Trailing needle

The trailing needle is "dragged" by the measuring value needle. As there is no fixed connection between the two needles, one-off maximum values are stored. The trailing needle can be reset using an adjusting dial in the window. Trailing needles cannot be used in connection with contacts.

Shut-off fitting

3-spindle valve block made of 1.4571, PN 100, DN 5, can be directly flanged

Functions: Shut-off, pressure compensation (Type DZ35)

on request

PTFE-coated seals (medium-compatibility) Special scales; housing made of 1.4571

Assembly

Wall mounting

Code W

by means of a wall assembly plate attached to the reverse

Pipe mounting

Code R

by means of a pipe assembly test for attachment to vertical or horizontal 2"-pipes

Direct panel mounting

Code T

Owing to the relatively heavy weight, only small measuring cells are suitable for directly mounting to the panel: Measuring ranges \geq 0.6 bar, measuring value display NG100 and NG160, without contact or transmitter fittings.

Panel mounting with front ring

Code G

All variants can be mounted to the panel using a supporting construction provided by the customer and a front ring set.

² See data sheet KE



Small measuring cell Ø75

| Measuring ranges | Measured Value Display | Magnetic spring contacts | | | Inductive contacts | | Capacitive angular position transduceers | Trailing needle | Marker needle | riange seal disage of the seal disage of the seal disage. The seal disage of the seal dis | | Pressure levels |
|------------------|---------------------------|--------------------------|---|---|--------------------|---|--|-----------------|---------------|--|--|-----------------|
| 040 mbar | | | | | | | | | | | | |
| 060 mbar | | | | | | | | | | | | |
| 0100 mbar | | | | | | | | | | | | |
| 0160 mbar | | | | | | | | | | | | |
| 0250 mbar | | | | | | | | | | | | |
| 0400 mbar | | | | | | | | | | | | |
| -4060 mbar | | | | | | | | | | | | |
| -60100 mbar | | | | | | | | | | | | |
| -100250 mbar | | | | | | | | | | | | |
| 00.6 bar | • | • | • | • | • | • | • | • | • | • | | |
| 01.0 bar | • | • | • | • | • | • | • | • | • | • | | |
| 01.6 bar | • | • | • | • | • | • | • | • | • | • | | |
| 02.5 bar | • | • | • | • | • | • | • | • | • | • | | |
| 04.0 bar | • | • | • | • | • | • | • | • | • | • | | |
| 06.0 bar | • | • | • | • | • | • | • | • | • | • | | N40 |
| 010 bar | • | • | • | • | • | • | • | • | • | • | | PN100 / PN40 |
| 016 bar | • | • | • | • | • | • | • | • | • | • | | P |
| 025 bar | • | • | • | • | • | • | • | • | • | • | | |
| -10.6 bar | • | • | • | • | • | • | • | • | • | • | | |
| -11.5 bar | • | • | • | • | • | • | • | • | • | • | | |
| -13 bar | • | • | • | • | • | • | • | • | • | • | | |
| -15 bar | • | • | • | • | • | • | • | • | • | • | | |



Size of the measuring cell Ø130

| Measuring ranges | Measured Value Display | Measured Value Display Magnetic spring contacts | | | Inductive contacts | | Capacitive angular position transducers | Trailing needle | Marker needle | Remote seal displacement volume | | Pressure levels |
|------------------|---------------------------|--|---|---|--------------------|---|---|-----------------|---------------|---------------------------------|--|-----------------|
| | | 1 | 2 | 3 | 1 | 2 | | | | Fischer | | |
| 040 mbar | • | | | | | | • | | • | | | |
| 060 mbar | • | • | • | | • | • | • | • | • | | | |
| 0100 mbar | • | • | • | | • | • | • | • | • | • | | |
| 0160 mbar | • | • | • | • | • | • | • | • | • | • | | N40 |
| 0250 mbar | • | • | • | • | • | • | • | • | • | • | | PN100 / PN40 |
| 0400 mbar | • | • | • | • | • | • | • | • | • | • | | P. |
| -4060 mbar | • | • | • | • | • | • | • | • | • | • | | |
| -60100 mbar | • | • | • | • | • | • | • | • | • | • | | |
| -100250 mbar | • | • | • | • | • | • | • | • | • | • | | |
| 00.6 bar | | | | | | | | | | | | |
| 01.0 bar | | | | | | | | | | | | |
| 01.6 bar | | | | | | | | | | | | |
| 02.5 bar | | | | | | | | | | | | |
| 04.0 bar | | | | | | | | | | | | |
| 06.0 bar | | | | | | | | | | | | |
| 010 bar | | | | | | | | | | | | |
| 016 bar | | | | | | | | | | | | |
| 025 bar | | | | | | | | | | | | |
| -10.6 bar | | | | | | | | | | | | |
| -11.5 bar | | | | | | | | | | | | |
| -13 bar | | | | | | | | | | | | |
| -15 bar | | | | | | | | | | | | |

 $\hfill \square$ on request




Dimensional drawings


(unless otherwise stated, all dimensions in mm)

Models

(A) For measuring ranges 40 ... 400 mbar



(B) For measuring ranges 0.6 ... 25 bar







Assembly


Flange connection

DIN EN 61518




Wall mounting (code W)






Pipe assembly set

Front ring (D) /panel cut-out (A, LK)






Installation of the panel using the panel installation set (code T)

Direct panel mounting (code G)



Accessories





Order Codes

| Differential pressure measuring unit | | | | | | | | |
|---|------------|------------|------------|----------|--|--|--|--|
| Small measuring cell Ø75 Type DA03 | | | | | | | | |
| Device model | † † | \uparrow | \uparrow | ↑ | | | | |
| DA03 PN40 measuring system 75 > G | | | | | | | | |
| DA03 PN100 measuring system 75 > K | | | | | | | | |
| broot into meadaining dystein rolling in a second rolling rolling in a second rolling rolling in a second | | | | | | | | |
| Measuring range | | | | | | | | |
| PN100 PN40 7 6 | | | | | | | | |
| 0 0.6 bar 0 0.6 bar 0 1 | | | | | | | | |
| 0 1.0 bar 0 1.0 bar> 0 2 | | | | | | | | |
| 0 1.6 bar 0 1.6 bar 0 3 | | | | | | | | |
| 0 2.5 bar 0 2.5 bar 0 4 | | | | | | | | |
| 0 4.0 bar 0 4.0 bar> 0 5 | | | | | | | | |
| 0 6.0 bar 0 6.0 bar 0 6 | | | | | | | | |
| 0 10.0 bar 0 10.0 bar 0 7 | | | | | | | | |
| 0 16.0 bar 0 16.0 bar 0 8 | | | | | | | | |
| 0 25.0 bar 0 25.0 bar 0 9 | | | | | | | | |
| -1 0.6 bar -1 0.6 bar 3 2 | | | | | | | | |
| -1 1.5 bar -1 1.5 bar 3 3 | | | | | | | | |
| -1 3.0 bar -1 3.0 bar 3 4 | | | | | | | | |
| -1 5.0 bar -1 5.0 bar 3 5 | | | | | | | | |
| Design of the measuring system | | | | | | | | |
| Pressure chamber chrome-nickel steel 1.4404 / AISI 316L | | | | | | | | |
| Measuring membrane standard R | | | | | | | | |
| Pressure chamber Hastelloy C4 | | | | | | | | |
| Measuring membrane Hastelloy C276 H | | | | | | | | |
| Pressure chamber chrome-nickel steel 1.4404 / AISI 316L Measuring membrane Hastelloy C276 G | | | | | | | | |
| modeling membrane risations, 6216 | | | | | | | | |
| Pressure connection | | | | | | | | |
| Flange connection similar to EN 61518 with internal thread G1/2 > 0 3 | | | | | | | | |
| Connecting piece with inside thread 1/4 18 NPT > 0 4 | | | | | | | | |
| Connecting piece with inside thread 1/2 14 NPT > 0 5 | | | | | | | | |
| Connecting pin with outer thread G1/2 B Niro 1 3 | | | | | | | | |
| Connecting pin with outer thread 1/4-18 NPT EXT Niro > 1 4 | | | | | | | | |
| Connecting pin with outer thread 1/2-14 NPT EXT Niro 1 5 | | | | | | | | |
| Cutting ring screw connection made of 1.4571 for 12 mm pipe > 2 7 | | | | | | | | |
| Measured Value Display | | | | | | | | |
| • • | | | | | | | | |
| Bayonet ring connector housing Ø 100mm 1.4301 | | | | | | | | |
| Bayonet ring connector housing Ø 160mm 1.4301 M | | | | | | | | |
| | ' | | | | | | | |
| Assembly option | | | | | | | | |
| Wall mounting | | | | | | | | |
| Pipe mounting | | | | | | | | |
| Panel mounting set (only for bar ranges / without additional add-ons) | T | | | | | | | |
| Front ring for panel mounting> | G | | | | | | | |
| Fluid charging | | | | | | | | |
| No fluid filling | > 0 | | | | | | | |
| Measuring value display with damping fluid glycerine (only for devices without contacts) | | | | | | | | |
| Measuring value display with damping fluid paraffin oil (for fitted inductive contacts) | | | | | | | | |
| Measuring value display with damping fluid silicone oil (for devices with and without contacts) | | | | 1 | | | | |
| (10 across min and minosi commonly minimum) | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |



Differential pressure measuring unit Small measuring cell Ø75 Type DA03 **Special functions** No special functions 0 Adjustable marker needle Resettable trailing needle Contacts/transmitters No contacts/transmitters > Built-in contacts as per data sheet KE Built-in capacitive angular position transducers as per data sheet KE09......> Built-in contacts with plug connector (power plant model) **Explosion protection / contacts** Standard model Device with switch contacts (simple electr. operating equipment acc. to DIN EN60079-11 Par.5.7) Device with switch contacts (inductive proximity switches) device with fitted capacitive angular position transducer


(1) Variant restriction

B: KE##M##0D4H2

C: KE##I##0C0H2

D: KE0905#90000







Differential pressure measuring unit Size of the measuring cell Ø130 Type DA03 **Special functions** No special functions Adjustable marker needle Resettable trailing needle (measuring ranges upwards of 60 mbar)......> Contacts/transmitters No contacts/transmitters > Built-in contacts as per data sheet KE ... for measuring ranges ≥ 60 mbar)> Built-in capacitive angular position transducers as per data sheet KE09, for measuring ranges ≥ 60 mbar> Built-in contacts with plug connector (power plant model) **Explosion protection / contacts** Standard model Device with switch contacts (simple electr. operating equipment acc. to DIN EN60079-11 Par.5.7) Built-in contacts as per data sheet KE ... for measuring ranges ≥ 60 mbar......> Device with switch contacts (inductive proximity switches) device with fitted capacitive angular position transducer (1) Variant restriction B: KE##M##0D4H2 C: KE##I##0C0H2

D: KE0905#90000

