### developing solutions







# Data sheet

## **DE39**

Digital differential pressure transmitter with colour-change LCD





## **1** Product and functional description

#### 1.1 Performance features

#### **Typical applications**

- · Differential pressure measurements in heavily soiled media
- Filter monitoring
- Simple pump control systems
- Pump and compressor monitoring

#### **Important features**

- 4-digit colour change LCD
- · Selectable operating mode
  - Differential pressure measurement
  - 2-channel relative pressure measurement.
- Selectable pressure unit
  - (bar, mbar, Pa, kPa, MPa, psi, InWc, mmHg)
- Selectable measured value display
  - Single-line presentation (channel 1 or channel 2)
    The respective other channel can be shown using the button **▲**
  - Two-line presentation (both channels)
- Zero point correction
- Signal damping
- 2 programmable output signals (current/voltage)
- Characteristic curve spread (max. 10:1) with freely selectable offset
- Characteristic curve implementation via table (with max. 30 measuring points)
- Full parameter setting and measuring point protocol possible thanks to optionally available transmitter PC interface

#### 1.2 Intended use

The devices of the series DE39 can be used as display and switching device for measuring differential pressure of gaseous and fluid media. Its sturdy design also allows heavily contaminated media to be used. Always check the medium compatibility [▶ 5].

#### 1.3 Design and mode of operation

The pressure is measured by two integrated ceramic sensor elements whose measuring signals P+ and P- are analysed by a digital measuring transducer. The analysis allows two independent switch points to be set and makes two programmable output signals available. The measurements can be shown together, separately or alternately. The nominal pressures of the integrated sensors and the differential pressure measuring range are set permanently exworks and stated on the type plate.

The unit works in two operating modes:

#### (a) Differential pressure measurement

The first output signal (Sig 1) is proportional to the differential pressure ( $\Delta P$ ) and can be influenced by means of rooting or a table. The second output signal (Sig 2) is proportional to the pressure and can be assigned optionally to the signal P + or P-.

#### (b) 2-channel relative pressure measurement

The output signals are proportional to the pressure, in which the output (Sig1) is permanently assigned to the pressure (P+) and the output (Sig2) is permanently assigned to the pressure (P-). Both output signals can be rooted or influenced by means of a table.

#### 1.4 Function diagram



Illustration 1: Function diagram

1	Ceramic sensor element	2	Micro-controller
3	Advertisement	4	Keyboard

- 5 Switching outputs
- 6 Analogue outputs

#### 1.5 Equipment versions

The appearance of the various models differs in terms of the process connection.



Illustration 2: Equipment versions

## 2 Technical data

#### 2.1 Input variables

#### Measuring variable

Differential and relative pressure

#### Measuring range

Measuring range		Overpres- sure	Bursting pressure
MPa	bar	bar	bar
00.6	6	20	35
01.0	10	40	70
01.6	16	40	70
02.5	25	100	150
04.0	40	100	150
	MPa 00.6 01.0 01.6 02.5	pressure max.        MPa      bar        00.6      6        01.0      10        01.6      16        02.5      25	pressure max.      sure        MPa      bar      bar        00.6      6      20        01.0      10      40        01.6      16      40        02.5      25      100

#### 2.2 Output sizes

#### Analogue output signal

Connection type: Three-wire Max. Spread: 10:1

Outlet	Signal range	Apparent ohmic resistance
0 20 mA	0.0 21.0 mA	$U_{b} \le 26 \text{ V}$ : $R_{L} \le (U_{b} - 4 \text{ V})/0.02 \text{ A}$
4 20 mA		$U_{b} > 26 \text{ V}$ : $R_{L} \le 1100 \Omega$
0 10 V	0.0 11.0 V	$R_L \ge 2 k\Omega$

#### Switching outputs

2 potential-free relay contacts

2 potential-free semiconductor switches (MOSFET)

	Relay	MOSFET
Progr. switching function	Open contact (NO) Break contact (NC)	One-pin activator (NO) One-pin deactivator (NC)
Max. switching voltage	32 V AC/DC	332 V AC/DC
Max. switching current	2 A	0.25 A
Max. switching output	64 W / 64 VA	8 W / 8 VA R <sub>oN</sub> ≤ 4 Ω

#### 2.3 Measurement accuracy

Non-linearity	Max	0.5 % FS
	Typical	0.2 % FS
Hysteresis	Max	0.5 % FS
	Typical	0.2 % FS
Characteristic curve deviation <sup>1)</sup>	Max	1.0 %
Temperature drift	Zero point	0.07 % FS/K
	Measuring range	0.05 % FS/K

<sup>1)</sup> incl. non-linearity and hysteresis

#### 2.4 Auxiliary energy

Rated Voltage	24 V AC/DC
Allowed operating voltage	12 32 V AC/DC
Power input	approx. 2 W (VA)

#### 2.5 Operating conditions

Increase ambient temper- ature	-10 +70 °C
Media temperature	-10 +80 °C
Storage temperature	-20 +70 °C
Enclosure protection class	IP65 as per EN 60529
EMC	EN 61326-1:2013 EN 61326-2-3:2013
RoHS	EN 50581:2012

#### 2.6 Display and operating interface

#### Advertisement

4...6-digit LCD, full graphic, colour backlighting

#### Programming

Attenuation	0.0 100.0 s (jump response time 10 / 90 %) for signal output; separately also for display
Switch output	Switch-off point, switch-on point, response time (01800s), function (NC / NO contact), channel assignment
Measuring range unit	bar, mbar, Pa, kPa, MPa, psi, InWc, mmWs, mmHg, 'free unit', starting value, end value and decimal point for 'free unit'
Output signal	User-definable within the basic measuring range <sup>(1)</sup>
Zero-point window	$01_3$ of the basic measuring range $^{(2)}$
Offset correction	$\pm 1/_3$ of the basic measuring range $^{(3)}$
Implementation of char- acteristic curve	linear, square rooted, table with 330 support points
Password	001 999 (000 = no password protection)
Language (can be switched)	DE, EN, FR, ES, IT, PT, and HU

(1) Max. effective spread 10:1

(2) measured values around zero are set to zero.

(3) To compensate different installation positions.

#### 2.7 Construction design

#### **Process connection**

Туре	the material.	Size
Inner thread	1.4404	G1/8
Cutting ring screw connection	1.4571	6 mm tube
Cutting ring screw connection	1.4571	8 mm tube
Cutting ring screw connection	Nickel-plated brass	6 mm tube
Cutting ring screw connection	Nickel-plated brass	8 mm tube

#### Materials

Housing	Polyamide (PA) 6.6
Media-contacting	CrNi steel 1.4404, FKM, Rubalit <sup>®</sup> 708 + Process connection
material	(see above)

#### Assembly

Attachment boreholes on the rear side for attachment to mounting plates. Wall mounting using wall mounting plate Panel mounting set for installing the panel Assembly of the mounting rails using an adapter

#### **Dimensional drawings**

#### Wall mounting



Cutting ring screw connection

Illustration 3: Dimensional picture

#### Attachment boreholes on rear side





## **3 Order Codes**



#### Measuring range:

[1.2]	(Code no.)
06	06 bar
07	010 bar
08	016 bar
09	025 bar
10	040 bar

#### Design:

[3]	(Code no.)
R	CrNi Steel 1.4404

#### **Approval variants:**

[4]	(Code no.)
0	Default

#### **Process connection:**

[5.6]	(Code no.)	
00	Inner thread G <sup>1</sup> / <sub>8</sub>	
24	Cutting ring screw connection made of 1.4571	for 6 mm tube
25	Cutting ring screw connection made of 1.4571	for 8 mm tube
28	Cutting ring connection made of brass galvanised	for 6 mm tube
29	Cutting ring connection made of brass galvanised	for 8 mm tube

#### Output signal:

[7]	(Code no.)	
0	without output signal	
4	0 20 mA	
5	0 10 V	
6	4 20 mA	
Operating voltage:		
[8]	(Code no.)	
К	24 V AC/DC	

႞၀႞	(Code no.)	
Κ	24 V AC/DC	

#### Measuring unit:

[9] (Code no.)
----------------

W Selectable pressure units

#### Measured value display / contact elements:

#### [10] (Code no.)

- C 4-digit colour change LCD
- dD 4-digit colour change LCD
- 2 relay contacts 2 semiconductor switches

#### **Electrical connection**

#### [11] (Code no.)

M M12 plug connection

#### Assembly:

- [12] (Code no.)
- **0** Attachment boreholes on rear side (standard)
- W Wall mounting

#### 3.1 Accessories

Order no.	Designation	No. of Poles	length
06401993	M12 Connection cable for switching outputs	4-pin	2m
06401994	M12 Connection cable for switching outputs	4-pin	5m
06401563	M12 Connection cable for switching outputs	4-pin	7m
06401572	M12 Connection cable for switching outputs	4-pin	10m
06401995	M12 Connection cable for supply/signal	5-pin	2m
06401996	M12 Connection cable for supply/signal	5-pin	5m
06401564	M12 Connection cable for supply/signal	5-pin	7m
06401573	M12 Connection cable for supply/signal	5-pin	10m

#### **Remote configuration**

Order no.		
EU05 0000	Transmitter PC interface incl. PC software	without battery
EU05 0001	Transmitter PC interface incl. PC software	With battery
EU03 F300	Transmitter PC interface incl. PC software	

A data sheet is available on our website <u>www.fischermesstechnik.de</u> or on request.

#### 3.2 Information about the document

This document contains all technical data about the device. Great care was taken when compiling the texts and illustrations; Nevertheless, errors cannot be ruled out.

Subject to technical amendments.



FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a D-32107 Bad Salzuflen Tel. +49 5222-974-0 Fax. +49 5222-7170

web : <u>www.fischermesstechnik.de</u> eMail : <u>info@fischermesstechnik.de</u>